



HOW TO CHANGE TIME ON YOUR HANDSETS

Panasonic

- Hang up the Phone
- Press “Prog” (Button on the screen)
- Dial **1234
- Dial 000
- Press “Enter”, Press “Next” to Change time
- Use keypad to change time
- Press “Enter” to save the new time